


## Spare Parts Catalogue

# PX8000-MONOFASE


### Generating sets

Valid for machine code: PK452SXB000


Revision: 0 (05/2013)



POSITION	PART NUMBER	DESCRIPTION	NOTES
20	PAA00101	MUFFLER ASSEMBLY PX8000	
86	PAA00541	Washer fixation ,wheel axle	
87	PAA00118	WHEEL ASSY 5000/8000	
88	PAA00122	WHEEL HUB CAP 4000/5000/8000	
89	PAA00115	SIDE COVER/MUFFLER SIDE 5000/8000	
90	PAA00114	SIDE COVER FOAM/MUFFLER SIDE 5000/8000	
95	PAA8000F	FRAME ASSY ENGINE GREEN PRAMAC	
96	PAA00116	SIDE COVER FOAM/ALTERNATOR SIDE 5000/8000	
97	PAA00117	SIDE COVER/ALTERNATOR SIDE 5000/8000	
100	PAA00119	SILENT BLOCK STUD BOLT 5000/8000	
106	PAA00120	SILENT BLOCK/SINGLE HEAD BOLT /DAMPING GLUE 5000/8000	
109	PAA00121	SILENT BLOCK A ENGINE 5000/8000	
110	SA40016052	FUEL TANK WITH SUPPLEMENTS	
112	G052956	RUBBER FEET 85 SH-A	
113	GA7021	FEET SUPPORT +NUT+SCREW	
115	PAA00111	HANDLE ASSY/PRAMAC GREEN ORANGE PEELED	
116	PAA00110	HANDLE FOAM SLEEVE	
117	PAA00121	SILENT BLOCK A ENGINE 5000/8000	
124	PEH16910-GB2-005	FILTER	
128	G085104	QUARTER TURN FUEL VALVE	
129	PAA80528	BATTERY	
131	G051521	SHELL FUEL CAP FOR METAL TANK - VENT HOLES ON TOP	
136	PAA00142	STRAINER FUEL 4000/5000/8000	
139	PAA00146	FUEL GAUGE TANK 4000/5000/8000	



POSITION	PART NUMBER	DESCRIPTION	NOTES
300	PAA80002	PANEL SUBASSEMBLY, CONTROL MONO	
301	G077009	DIGITAL MULTIMETER FOR PANEL (92V-260V) (50-60Hz)	
302	P3SN00052	SOCKET CEE IP44 16A 2P+T 230V	
303	P3SN00055	PRESA INCASSO DIRITTA CEE IP44 32 A 2P+T 230V	
304	G071131	SOCKET SUBASSEMBLY, POWER SUPPLY	
305	PGT00176	SWITCH ASSEMBLY	
305	PAA80007	START SWITCH KEY	
306	PGT62048	BREAKER SINGLE-POLE CIRCUIT 230V 22A	




POSITION	PART NUMBER	DESCRIPTION	NOTES
301	PAA00103	ALTERNATOR END COVER 5000/8000	
304	PAA00105	BRACKET, MOTOR 5000/8000	
305	PAA00104	BRUSH SUBASSEMBLY, CARBON 5000/8000	
308	PAA80004	AVR SINGLEPHASE PX8000	
399	PAA8000A	COMPLETE ALTERNATOR SINGLE PHASE	





POSITION	PART NUMBER	DESCRIPTION	NOTES
502	PAA00500	PLUG SPARK 5000/8000	
503	P3KI00299	Kit Pramac Power	
504	PAA00525	IGNATION COIL ASSY 5000/8000	
505	PAA00521	STARTER ASSY 5000/8000	
506	PAA00506	COMPLETE AIR FILTER CASE 5000/8000	
507	PAA00513	SENSOR ENGINE OIL 5000/8000	
508	PAA00505	CARBURATOR ASSY 8000	
515	PAA80526	STARTING MOTOR ASSY	
516	PAA80527	STARTER RELAY	
517	PAA00531	COPERCHIO FILTRO ARIA PX 5000/8000	



POSITION	PART NUMBER	DESCRIPTION	NOTES
503	PAA00507	GASKET CYLINDER HEAD 5000/8000	
505	PEH12391-ZE2-020	HEAD COVER GASKET GX390VXB	
506	PGT00513	SPRING VALVE 6200/6250/7000	
513	PAA00508	VALVE EXHAUST 5000/8000	
514	PAA00509	VALVE INTAKE 5000/8000	
515	PAA00503	EXHAUST VALVE SPRING RETAINER 5000/8000	
516	PAA00514	PROTECTOR OIL 5000/8000	
518	PAA00502	INLET VALVE SPRING RETAINER 5000/8000	
523	PAA80511	PISTON	
524	PAA00519	GASKET CARTER ENGINE 5000/8000	
525	PAA80512	ROD, CONNECTING	
526	PAA00518	OIL CAP 5000/8000	
527	PAA00515	SPRING GOVERNOR 5000/8000	
528	PAA00516	SPRING THROTTLE VALVE 5000/8000	
533	PAA00520	SEAL OIL 5000/8000	
534	PAA80510	RING SET, OIL KIT	
535	PAA80510	RING SET, OIL KIT	
536	PAA80510	RING SET, OIL KIT	
537	PAA00534	Cam shaft assy	